




SWITCH SOCKET					
No.	Product Discription	Small Button		Big Button	
		White	Color	White	Color
1	1 Gang 1 way	115.00	190.00	185.00	240.00
2	1 Gang 2 way	160.00	250.00	210.00	300.00
3	2 Gang 1 way	220.00	320.00	280.00	350.00
4	2 Gang 2 way	290.00	380.00	310.00	430.00
5	3 Gang 1 way	300.00	425.00	345.00	440.00
6	3 Gang 2 way	380.00	520.00	-	-
7	4 Gang 1 way	360.00	480.00	450.00	550.00
8	5 Gang 1 way	440.00	580.00	-	-
9	Bell Push	290.00	380.00	-	-
10	20A DP Switch with Neon	630.00	650.00	-	-
11	32A DP Switch	620.00	700.00	-	-
12	Blank Plate	65.00	-	-	-
13	10 A 2 pin Scket with Switch	315.00	400.00	-	-
14	13A 3 pin Socket Switch (neon) Flat	330.00	400.00	-	-
15	15A 3 pin Round Socket Switch	440.00	520.00	-	-
16	10 A 3 pin Universal Socket with Switch	380.00	440.00	-	-
17	Telephone Socket (RJ 11)	345.00	430.00	-	-
18	TV/Dish Socket	345.00	430.00	-	-
19	Fan control Dimmer with Switch	750.00	920.00	-	-
20	13A, 3 Pin Un Socket+2 pin Socket	350.00	430.00	-	-
21	13A, 3 pin Un. Socket+ 2 pin Socket with Switch	400.00	470.00	-	-
22	Data Socket (RJ 45)	550.00	600.00	-	-



SOME SPACIAL PRODUCT

<p>13A 3 pin Socket</p>	<p>16A 3 pin Socket</p>	<p>13A 3 pin Socket + 1USB</p>	<p>TV & Data Socket</p>	<p>2 Gang 13A 3 pin Socket</p>
<p>Button Control Time Delay Switch</p>	<p>Sound & Light Control Time Delar Switch</p>	<p>Light Dimmer Switch</p>	<p>Porch Lamp Switch</p>	<p>2 Gang 13A 3 pin Socket</p>